WALL STAND

This device holds a wall upright in order to install the door or window within a wall panel. Usually, we have one of these on each side of a wall for stability when working on it (see page 27, **fig. 5**). To insert a wall into the arms you loosen the pivot bolt until you can insert a wall component between the arms, and then you tighten the bolt back up. To prevent scratches to the wood paneling there is carpet glued to the insides of the arms that hold the wall upright.