

(15) Modify a hollow-core door to fit the vertical measurement of the front wall's rough door opening. (See door construction on page 23.)

(16) Hang the door with two $3\frac{1}{2}$ " hinges to the appropriate side of the opening.

NOTE: We don't explain the whole process of hanging a door. If you don't know how to hang a door, basic instructions can be found with a quick internet search.

(17) Install door-jam strips around the interior perimeter of your door. We use strips of $\frac{3}{4}$ "X $\frac{3}{4}$ " cedar.

(18) Finally, nail the exterior trim to your wall panel using $2\frac{1}{2}$ " galvanized finish nails.

The front wall panel is now complete!



Figure 10. Finished front wall panel with door, finish trim, vent screen, and temporary footer for moving wall around