



Step 5E: Once the panel is in a near-perfect position, hold it while volunteers use the plumbers tape fasteners and $1\frac{1}{4}$ " deck screws to attach it to the side with the chalk line first. Then do the other side. For starters, just put four or five fasteners into the 2X6 floor joist, along the bottom only. You will fasten the other points later. **Figure 5F** shows a close up of the fastener being attached with the bottom of the cattle panel lined up with the chalk line.

Step 5G: Okay, with the bottom secure, we recheck to make sure the rear wall is plumb and fasten the panel to the 2X4 wall brace close to the wall to hold it plumb. Then it's time to get and fasten another panel, and then another, and then a half panel (see **fig. 5K**). Each new panel should be brought over the front of the Hut toward the rear and fastened first to the bottom following the chalk line.

Step 5H: As new panels are being fastened, a volunteer can begin tying the panels together with the rebar ties using the twister tool. We use seven wire sections per seam.

