Figure 2. (Bottom view) Use 3/8" T-50 staples to attach the moisture barrier fabric and then use an air stapler with 18 ga. 1" staples to attach lath sticks to reinforce the fabric.

Figure 3. Insulated floor section ready to receive the subfloor panels

IMPORTANT NOTE: Use the 3-4-5 rule to make sure your floor frames are squared before attaching the plywood flooring. Go to YouTube and watch a video if you need more info about the 3-4-5 rule!

BASIC ORDER FOR CONSTRUCTING THE FLOOR SECTIONS:

(1) Cut and fasten together the floor framing pieces (**fig. 1**).

(2) Staple moisture barrier and lath sticks to the bottom side of framing (**fig. 2**).

(3) Flip the floor over, insert and staple insulation with paper side up (**fig. 3**).

(4) Cut and attach the plywood flooring to framing (**figs. 4–5**).

(5) Apply two coats of latex floor paint to plywood (**fig. 6**).