Figure 4. Window trim pieces and measurements

Trim measurements

Name	Length	QTY
T3-	39⅛"	1
*T4-	24¼"	2
T5-	41"	1

Width of trim pieces is 2¼"

* Measurements of the cut out notches are ⅞" wide X 2⅝" tall.

Figure 5. A finished back wall panel

(7) Insert a 3'X2' vinyl slider window into the rough opening. After centering the window in the frame, use 1¼" exterior screws to fasten the vinyl window to the wall by screwing thru the window flange. We use 6–8 screws.

(8) Nail the four trim pieces to your wall panel, over the window flange, using 2 ½" galvanized finish nails (**fig. 5**).

NOTE: There are many ways to hang a window and lots of different opinions for how to do it right. Like the door hanging process, we don't go into detail about how to do this. We recommend getting more information from online sources if you need it.