Step 3D: Notice the board that is temporarily attached to the inside face of the front wall panel. Its purpose is to hold the proper spacing of the door opening when the temporary footer gets removed. Preserving the width of the door opening is critical to maintaining a door that opens and closes easily. You can take this board off after the wall is attached to the floor component.

Step 3E: Tape up the wall-end material where it was cut, and you are ready to move onto the next step. Keep in mind that the walls will still move forward and backwards a little, so they are not ready for you to lean up against them and take a break.