Step 7E: Unroll the TPO over the interior portion. This usually requires three people, one on a ladder in the middle of the roll. Unroll enough of the material so the free end is near the bottom of the Hut. Then, working together, push the rest of the roll over the top (being sure to warn anyone on the other side!).

Step 7F: Follow a similar procedure as in **7B** to set one side at the finished length. Make sure the TPO is covering all the interior by measuring from the outside of the overhangs to the vertical edge of the TPO in both front and back. The desired measurements are approximately 44" in front and 10" in back. You can double check by measuring from the outside of the walls to the outside of the vinyl-covered cattle panel.

STEP 7G: Attach the TPO to the floor framing in the same manner as the vinyl (**7C**).

STEP 7H: Using a good sharp razor knife, cut off the excess material along the second bottom edge you attached, leaving enough to tuck neatly under the floor framing.

STEP 7I: Do a final clean up around the newly built Conestoga Hut. Look for any hardware or inconspicuously placed tools that might be left behind.