PARALLELISM Jun 20, 2018

@Jessica when the XY 0 button gets pushed by accident and the head beats against the hard stop there's a high probability that the belt might slip and the bed will become no longer parallel with the rail. Use the 3" blocks to check parallelism.

BED LEVELING is a misnomer. The goal is not to level the bed. The goal is to make the bed parallel to the cross arm. Use the 3" spacer blocks at each end of the arm for reference.

Turn off the power. Tug on the belts. An assistant to watch the progress and give feedback to the belt guy is very helpful.